

Esc	F1	F2	F3	F4	F5	F6	F7	F8	F9	F10	F11	F12
1BH 1BH 1BH 1BH 1BH	F1H F1H EEH, F1H F1H F1H	F2H F2H EEH, F2H F2H F2H	F3H F3H EEH, F3H F3H F3H	F4H F4H EEH, F4H F4H F4H	F5H F5H EEH, F5H F5H F5H	F6H F6H EEH, F6H F6H F6H	F7H F7H EEH, F7H F7H F7H	F8H F8H EEH, F8H F8H F8H	F9H F9H EEH, F9H F9H F9H	FAH FAH EEH, FAH FAH FAH	FBH FBH EEH, FBH FBH FBH	FCH FCH EEH, FCH FCH FCH

PRNT SCRN	SCRL LOCK	PAUSE
FDH FDH EEH, FDH FDH FDH	FEH FEH EEH, FEH FEH FEH	FFH FFH EEH, FFH FFH FFH

1	2	3	4	5	6	7	8	9	0	-	=	\	BK SPC	
60H 7EH EEH, 60H 00H 60H	31H 21H EEH, 31H 31H 31H	32H 40H EEH, 32H 32H 32H	33H 23H EEH, 33H 33H 33H	34H 24H EEH, 34H 34H 34H	35H 25H EEH, 35H 35H 35H	36H 26H EEH, 36H 36H 36H	37H 26H EEH, 37H 37H 37H	38H 2AH EEH, 38H 38H 38H	39H 28H EEH, 39H 39H 39H	30H 29H EEH, 30H 30H 30H	2DH 5FH EEH, 2DH 2DH 2DH	3DH 2BH EEH, 3DH 3DH 3DH	5CH 7CH EEH, 5CH 5CH 5CH	08H 08H 08H 08H 08H

INSERT	HOME	PGUP
C0H C0H C0H C0H C0H	C1H C1H C1H C1H C1H	C2H C2H C2H C2H C2H

NUM LOCK	/	*	-
NO CODES	C6H C6H C6H C6H C6H	C7H C7H C7H C7H C7H	C8H C8H C8H C8H C8H

TAB	Q	W	E	R	T	Y	U	I	O	P	[	]	ENTER
09H 09H 09H 09H 09H	71H 51H EEH, 71H 11H 71H	77H 57H EEH, 77H 17H 77H	65H 45H EEH, 65H 05H 65H	72H 52H EEH, 72H 12H 72H	74H 54H EEH, 74H 14H 74H	79H 59H EEH, 79H 19H 79H	75H 55H EEH, 75H 15H 75H	69H 49H EEH, 69H 09H 69H	6FH 4FH EEH, 6FH 0FH 6FH	70H 50H EEH, 70H 10H 70H	5BH 7BH EEH, 5BH 1BH 5BH	5DH 7DH EEH, 5DH 1DH 5DH	0DH 0DH 0DH 0DH 0DH

DELETE	END	PGDN
C3H C3H C3H C3H C3H	C4H C4H C4H C4H C4H	C5H C5H C5H C5H C5H

7-HOME	8-UP	9-PGUP	+
D7H D7H EEH, D7H D7H 37H	D8H D8H EEH, D8H D8H 38H	D9H D9H EEH, D9H D9H 39H	C9H C9H C9H C9H C9H

CAPS LOCK	A	S	D	F	G	H	J	K	L	;	'	
NO OUTPUT, MODIFIES CODES ONLY	61H 41H EEH, 61H 01H 61H	73H 53H CONFIG 13H 73H	64H 44H EEH, 64H 03H 64H	66H 46H EEH, 66H 06H 66H	67H 47H EEH, 67H 07H 67H	68H 48H EEH, 68H 08H 68H	6AH 4AH EEH, 6AH 0AH 6AH	6BH 4BH EEH, 6BH 0BH 6BH	6CH 4CH EEH, 6CH 0CH 6CH	3BH 3AH EEH, 3BH 1BH 3BH	27H 22H EEH, 27H 07H 27H	

4-LEFT	5	6-RIGHT
D4H D4H EEH, D4H D4H 34H	D5H D5H EEH, D5H D5H 35H	D6H D6H EEH, D6H D6H 36H

SHIFT	Z	X	C	V	B	N	M	,	.	/	SHIFT
NO OUTPUT, MODIFIES CODES ONLY	7AH 5AH EEH, 7AH 1AH 7AH	78H 58H EEH, 78H 18H 78H	63H 43H EEH, 63H 03H 63H	76H 56H EEH, 76H 16H 76H	62H 42H EEH, 62H 02H 62H	6EH 4EH EEH, 6EH 0EH 6EH	6DH 4DH EEH, 6DH 0DH 6DH	2CH 3CH EEH, 2CH 0CH 2CH	2EH 3EH EEH, 2EH 0EH 2EH	2FH 3FH EEH, 2FH 0FH 2FH	NO OUTPUT, MODIFIES CODES ONLY

UP ARROW
DAH DAH EEH, DAH DAH DAH

1-END	2-DN	3-PGDN	ENTER
D1H D1H EEH, D1H D1H 31H	D2H D2H EEH, D2H D2H 32H	D3H D3H EEH, D3H D3H 33H	CAH CAH CAH CAH CAH

CTRL	ALT	SPACE	ALT	CTRL
NO OUTPUT, MODIFIES CODES ONLY	NO OUTPUT, MODIFIES CODES ONLY	20H 20H 20H 20H 20H	NO OUTPUT, MODIFIES CODES ONLY	NO OUTPUT, MODIFIES CODES ONLY

LEFT ARROW	DOWN ARROW	RIGHT ARROW
DBH DBH EEH, DBH DBH DBH	DCH DCH EEH, DCH DCH DCH	DDH DDH EEH, DDH DDH DDH

0-INSERT	.-DEL
D0H D0H EEH, D0H D0H 30H	DEH DEH EEH, DEH DEH 2EH

Order of precedence for control keys:

- 1) ALT key(s)
- 2) Control Key(s)
- 3) NumLock
- 4) SHIFT key(s)

Key Legend
Normal Key Value
Shifted Key Value
ALT Key Value
Control Key Value
NumLock Key Value